



SLOW START

Sets the number of main shaft rotations for which the main shaft rotates at a slow speed when starting sewing after thread trimming.



1 Select "6. SLOW START" (slow start).


```
=== FUNCTION MENU ===  
4. LOCK ST. → So Eo  
5. SATINADJ. → OFF  
6. SLOW START → 2 ST
```

Press  .
Move the cursor using  (hoop travel key).

2 Select the setting.

```
=== FUNCTION MENU ===  
4. LOCK ST. → So Eo  
5. SATINADJ. → OFF  
6. SLOW START → 2 ST
```

Select "2"... or "9" using the following keys:
 and  (hoop travel keys)

 Setting: 2 - 9 stitches
The number of stitches for slow start

3 Press [SET] to confirm the setting.

```
=== FUNCTION MENU ===  
4. LOCK ST. → So Eo  
5. SATINADJ. → OFF  
6. SLOW START → 2 ST
```

Press  .