

**PRO**<sup>®</sup>  
CAPSULE


A red arrow pointing upwards, positioned to the right of the word 'CAPSULE' and partially overlapping the 'E'.

**REFERENCE GUIDE**

**Index**

Control Panel Operation fixture .....	1
Load Design Into Machine Memory .....	2
Select Design From Memory .....	2
Enter Color Changes .....	3
Center The Design .....	3
Trace Design .....	4
Replace or Modify color .....	5
Star the embrioidery Machine .....	6
Manual or Automatic color change .....	7
Moving Forward or backward .....	8
Cap or Flat Embroidery Mode .....	8

## Control Panel Operation



### Trace Design Before You Press Start !

1. Move needle #1 to the sewing position by pressing 1.
2. Center the frame.
3. Press the Home button.
4. Scroll to or press 5.
5. Press the Enter button to begin the frame movement.
6. Watch needle #1 to insure it will sew inside the hoop.
7. Repeat the process if in doubt !

## Load design Into Machine Memory

1- Press the Embroidery Set/Relieve button,  then press  **ENTER**

2- Insert the flash drive in the USB machine slot

3- Press  **(Machine Memory)**

4- Scroll down or press #2 **(Input Design to Memory)** and then press 

5- Select the Design. There only will be 10 designs at the time to view

For next page press  or previous page  and then press  **ENTER**

6- Machine will display a memory # at this point. Press  **ENTER** again.

7- Press  **ESC** to get back to the Machine Memory menu.

## Select Design From Memory

1- Press  **(Machine Memory)**

2- Press #1 **(Select Design For Embroidery)** then press  **ENTER** to select.

3- Search for design by pressing the **UP** or **DOWN** arrow then press  **ENTER**

At this point a screen with design information will appear. Press  **ENTER** again.

## Enter Color Changes

1- Press  (Set Color Sequence)

2- Press #1 (Set Color Order) and then press 

3- Move the Cursor to the Color 1 position and start entering the color(s).


**Note:** For 2-digit numbers 10 to 15, press 10+ followed by the number.

**Example** enter number 12 needle color you will have to press 10+ then 2

4- After all colors are entered press 

## Center The Design

1- Press #1 on the key pad to move the machine head to needle 1 position

2- By pressing the position arrows,  center the hoop under needle #1

3- After centering the hoop, press the  (Return to origin)

4- Scroll to or press #3 (Set Start) and press  ENTER.

a Box will appear **SET START POSITION?** Press  ENTER again

5- To reposition the center ,follow the step 3

## Trace Design

- 1- Make sure to move the machine to needle #1 before tracing
- 2- Press  (Return to origin)
- 3- Scroll down or Press #5 (**Design Range Check**) and press  ENTER  
The machine will start tracing on square.
- 4- Repeat the process if in doubt



## Trace Design Before You Press Start !

Watch the needle #1 to insure it will sew inside of the hoop  
Repeat the process if in doubt !

## Replace or Modify a Color

- 1- Press  Set Color sequence
- 2- Scroll down to or Press #2 then  ENTER
- 3- A box will appear to enter the color number to be replaced


INPUT	
ND A Replace	ND B Replace
B: <input type="text" value="0"/>	A: <input type="text" value="0"/>
<input type="button" value="ENTER"/>	<input type="button" value="ESC"/>

**B:** is the current color number or needle  
**A:** is the new color or needle to be change to


- 4- After change color press  ENTER  
Then Press  **ESC** to get out of that option

## To Start the Embroidery Machine

- 1- Make sure that the machine is set by pressing the set or release button  
Before star working (PIC #1)



Embroidery set when the icon on screen is Yellow (PIC #1)



Embroidery not set when the icon on screen is Red and is blinking (PIC #2)

## Manual or Automatic Color Change

1- Press  (Manual/Automatic Color Change) The machine will change on 3 stages


a)- Press  First time will change to blue.

That means the machine will sew the same color again. (pic #1)


b)- Press  Second time will change to red.

That means the machine will sew one color and stop after each color change. (pic #2)


c)- Press  Again will set the machine back on automatic color change. (pic #3)



(pic #1)



(pic #2)



(pic #3)

## Moving forward / backward

While the machine is embroidering it can move as many stitches you need backward just by pressing **STOP**. The machine will back up.

Moving Forward Press  (**Manual Automatic Color Change**)

Until color change Icon changes to red then press **START**


## Cap or flat embroidery Mode

1- Before install and run caps, make sure the machine is set on Cap mode

by pressing  (Cap / Flat Mode)

2- The lower corner will show a cap (pic #1) 


3- Also make sure to flip the design over by pressing  (Rotate Design)



Rotate direction

(Pic #1)

Cap Mode



Flat Mode

Make sure that the **F** is on the right position (**Pic #1**) to avoid unwanted embroidery direction.

4- To center the cap, follow the steps describe on **Trace Design**